## 1 Find a Location for Your Radio and Mount It


Select either the Dash Mount method or the Vent Mount method for your Starmate 8. You will need a phillips-head screwdriver to complete the installation.

IMPORTANT! You can take advantage of the wire guide channel across the back of the Vehicle Dock to organize the wires which connect to the dock.


## Dash Mount Method:


IMPORTANT: The air temperature needs to be at least 15°C/60°F to install the Dash Mount. If needed, turn on the heater in your vehicle.


A. Select a flat surface for the Dash Mount with ample room for Starmate 8. Avoid mounting on leather surfaces. Choose a location that doesn't interfere with the driver's vision or access to driving controls, one that won't interfere with the deployment of airbags or other safety equipment, and makes Starmate 8 easily accessible for operation. (Airbag locations are typically marked with "SRS" logos.)


























- E. Once the surface is dry, remove the adhesive liner. Press and hold the Dash Mount in place for 30 seconds. Allow the adhesive to cure for 2-4 hours.
- **F.** You can tilt the dock mounting plate in your preferred direction.






A. Select a vent with ample room for Starmate 8, one that won't interfere with the deployment of airbags or other safety equipment, and makes Starmate 8 easily accessible for operation. (Airbag locations are typically marked with "SRS"






B. Some vents have recessed louvers. If yours are recessed, remove the regular vent clamps and install the extended vent clamps.











## **C.** Attach the Dash Mount to the *Power*Connect Vehicle Dock using the 4 provided screws. If you plan to use the wire guide channel across the back of the Vehicle Dock to organize the wires, do not fully tighten the screws. If not, tighten the screws.



- i. Insert the vent mount into the vent opening.
- ii. Push until hooked on the rear of the vent louver. Rest the foot against the bottom of the vent.
- iii. If necessary, adjust the tilt of the Vent Mount by repositioning the foot to a different tilt adjustment



# 2 Mount the Magnetic Mount Antenna

- **A.** Mount the Magnetic Mount Antenna outside your vehicle, on a clean and dry horizontal surface that will always face the sky.
- **B.** Choose the location for the antenna according to your type of vehicle. Center it between the left and right sides, and away from other antennas.












(rear of roof)

# TIP: Use the Alcohol Prep Pad to clean the surface.


# 3 Route the Antenna Cable









- C. Lift the weather stripping. Tuck and run the cable inside it to the bottom of the door opening. Replace the weather stripping.
- **D.** Pull the cable out and route it to Starmate 8.
- E. Plug the Magnetic Mount Antenna connector into the silver ANT connector on the side of the PowerConnect Vehicle Dock.








# 5 Verify Signal Reception

- A. Be sure the vehicle is outside and the antenna has a clear view of the sky.
- B. Verify that you are receiving the Sirius XM signal. The radio should be tuned to channel 184, the Preview channel. There should at least be one bar on the lower left corner of the screen that denotes
- You can also press **menu** and then press ▼ to scroll to and highlight Signal To Activate, Call Indicator, Press the Select button. The Satellite and Terrestrial bars show the 888-539-7474 strength of the signal being received. If the signal reception is good, press and hold **menu** to return to channel 184, the Sirius Preview channel.






# 4 Connect the *Power*Connect Power Adapter

A. Insert the PowerConnect Power Adapter into your vehicle's cigarette lighter or power adapter socket. Plug the other end into the red PWR connector on the side of the PowerConnect Vehicle Dock.



**B.** Place Starmate 8 into the dock and press the **Power button**.





## 6 Connect the Audio

Decide on one of the following in-box audio connection options. Refer to "Connect the Audio" in the User Guide for details including other connection options. The User Guide is available at siriusxm.ca/userguides.

Option 1: Best: Use the provided Aux In Cable, if your vehicle's stereo system has an auxiliary input jack.

- A. Plug one end of the cable into the green AUDIO connector on the side of the PowerConnect Vehicle Dock and the other end into the auxiliary input lack on the vehicle's stereo system.
- B. Turn on your vehicle's stereo system and set it to play from the auxiliary input source.
- C. You should now hear the Sirius Preview channel 184. The installation is complete.
- **D.** If you are using the wire guide channel across the back of the Vehicle Dock to organize the wires, place the wires in the

guide and then tighten the 4 screws to securely attach the mount. The installation is complete.

RUXINMODE

FM Channels

FM 1 97.9 current

Edit FM Channel 2

FM Channel 2

TIP! Refer to your vehicle's owner's manual to find the location of the auxiliary input jack, or consult the vehicle dealer.

Option 2: Good: Use the *Power*Connect™ feature of Starmate 8. *Power*Connect plays the Sirius audio through your vehicle's FM radio.

- A. Find and make a list of all available FM channels in your area that are not being used by an FM radio station.
- B. Pick the first FM channel on your list. Tune your vehicle's FM radio to this FM channel. C. Set your Starmate 8 to transmit on the same FM channel that you have selected on your vehicle's
- i. Press menu and then press ▼ to scroll to and highlight FM Settings. Press the Select button.
- ii. Press ▼ to scroll to and highlight FM Channels. Press the Select button. iii. Press veroll to and highlight FM2. Press the Select button.
- iv. Press ◀ and ▶ to tune in steps of .2, or press ▼ and ▲ to tune in steps
- FM 5 \_ \_ \_ of 1 to select the available FM channel you have chosen. Press the Select button to select the FM channel.
- v. Start Using will be highlighted. Press the Select button.
- vi. The selected FM channel will be confirmed on the display screen, and Starmate 8 will tune to the FM channel. Press and hold menu to return to the main display screen.
- D. You should now hear Sirius channel 184 through your vehicle's FM radio. If you are not satisfied with the audio quality, move to the next FM channel on your list and repeat the process. Continue until you have found an FM channel with which you are satisfied.
- E. If you are using the wire guide channel across the back of the Vehicle Dock to organize the wires, place the wires in the guide and then tighten the 4 screws to securely attach the mount. The installation is complete.



# Subscribe

You can either follow the general activation and subscription process or use the on-board activation guide to activate your Starmate 8 and subscribe to the Sirius service.

### General activation and subscription process:

- A. Make sure your Starmate 8 is turned on, tuned to Sirius Preview channel 184, and receiving the Sirius signal so that you can hear the Sirius audio.
- B. When you first turn on Starmate 8, the Sirius channel lineup may automatically update after the initial startup sequence. Wait until any channel updates have completed before pressing any buttons. Once the channels have been updated, the Radio will automatically tune to channel 184.
- C. Make a note of the Sirius ID. You can find it:
- by selecting Sirius ID in menu items
- on channel O (zero)
- on a label on the bottom of the gift box • on the label on the back of your Starmate 8
- **D.** To subscribe:
  - Online: Go to siriusxm.ca/activate to access or set up an online account, subscribe to the service, and activate your Radio.
- By phone: Call 1-888-539-7474
- E. Activation usually takes less than 5 minutes after you have completed the subscription process, but sometimes may take longer. We recommend that your Radio remain on until activated. When your service is activated. Starmate 8 will display an alert message. To 4 Margaritaville continue, press any button.

Press ▲ or ▼ to tune to other channels, and ◀ or ▶ to browse the different categories of channels. Learn what all the buttons do in the next box.

### Activation quide:

For your convenience, Starmate 8 has an on-board activation quide. You can activate your radio and subscribe to the Sirius service by using this guide, where you will be guided step-by-step through the subscription process. To access and use the guide, simply follow these steps:

- A. When you first turn on Starmate 8, the Sirius channel lineup may automatically update after the initial startup sequence. Wait until any channel updates have completed before pressing any buttons. Once the channels have been updated, the Radio will automatically tune to Sirius Preview channel 184.
- B. Press menu.
- C. Activate Radio will be highlighted. Press the Select button.
- **D.** Follow the directions on each successive screen until you complete the subscription process.





ubscription Updat

# Starmate 8 Main Display

channel, press and hold to store live radio.

Press to tune to a stored favorite Pause, rewind, and replay

**Starmate 8 Button Functions** 

**STARMATE** 

a favorite channel: also enter a

channel number.

SIRIUS**%** 

When listening to a channel, information about the channel and what is currently playing is displayed.



# What's in the Box?



options, press and hold

screen.

FM Button

to return to main display

Press to access and cycle

Press to go back to the

which you were listening

previous channel to

Direct Button


Press first before


entering the channel

number, to directly

tune to a channel.

through FM presets.





Vent Clamps

















PowerConnect Power Adapter




















© 2016 Sirius XM Radio Inc.

siriusxm.ca

1-888-539-7474

Sirius XM Canada Inc.

135 Liberty St. - 4th floor

Toronto, Ontario, M6K 1A7

What This Warranty Covers

LIMITATIONS OF LIABILITY

have other rights, which vary from province to province.

Sirius XM 12-Month Limited Warranty

his warranty covers defects in material and workmanship for 12 months from the date of purchase by the original retail purcha

varranted to be free from defects for 30 days or the remainder of the original warranty, whichever is longer.

moval, use of third party accessories, mishandling, misuse, neglect, accident, power surges or acts of nature.

escription of the defect. You must prepay the cost of shipping the product to an approved service center.

nly. SiriusXM Canada Inc., at its sole option, will repair or replace the product with a new or reconditioned product witho

harge for parts and labour. Products replaced under this warranty become the property of SiriusXM. Replacement products are

his warranty does not cover; products sold as used, as is, reconditioned or refurbished; software stored on internal or removable

emory: non-rechargeable batteries, surface preparation cleaners, adhesive pads, fasteners, and ear-buds: costs incurred

or installation, removal or reinstallation of the product; correction of installation problems, such as elimination of externally

enerated static or noise and antenna placement and aiming; defects or damage caused by alteration, improper installation or

obtain warranty service, please call Customer Care at 1-888-539-7474. You will be required to provide proof of purchase and a

HE LIABILITY OF SIRIUSXM UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT AS PROVIDED ABOVE AND

N NO EVENT SHALL THE LIABILITY EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT. ANY IMPLIED WARRANTIE

ICLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SHALL BE LIMIT

ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN 48 MONTHS FROM THE DATE OF ORIGINA

D THE DURATION OF THIS WRITTEN WARRANTY, ANY ACTION FOR BREACH OF WARRANTY, INCLUDING BREACH O

JRCHASE. IN NO CASE SHALL SIRIUSXM BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH

F THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED. SOME PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG

N IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO TH ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. This warranty gives you specific legal rights and you may also

If you experience problems with the operation or performance of your product

DO NOT RETURN THIS PRODUCT TO YOUR RETAILER

Call Customer Care at 1-888-539-7474

Self installation instructions and tips are provided for your

convenience. It is your responsibility to determine if you have

the knowledge, skills and physical ability required to properly

perform an installation. Sirius XM shall have no liability for

damage or injury resulting from the installation or use of an

to ensure that all products are installed in adherence wit

a vehicle to be operated safely and without distraction

or reinstallation of any product.

local laws and regulations and in such a manner as to allow

SiriusXM warranties do not cover the installation, removal

This Class B digital apparatus complies with Canadian

This device complies with Industry Canada license-exemp RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and

(2) this device must accept any interference, includir

interference that may cause undesired operation of the

SiriusXM or third party products. It is your responsib

# ((SiriusXM))

Quick Start Guide

Starmate 8 Radio & Vehicle Kit